

## RETROFIT 1 2 3 4 5 6 7 8 9 0 v

1300 AU BURG www.burgaustralia.au sales@burgaustralia.au

## BURG





## Old out.

Retrofit refers to the modernization of existing (usually older) locking systems. Retrofit locking systems are designed in such a way that the existing installation situation can be retained. The locking system can be screwed into the existing hole without time-consuming drilling and milling.

Retrofitting often eliminates the need to purchase new furniture. However, existing steel or even wooden cabinets can be integrated into a modern access control system using retrofit locking systems, even radio-networked if desired. Future-proof for sure!

## New in.

19 mm

A16mm x 19mm mounting hole has become the industry standard for many pieces of steel and wood furniture. Many cabinet and locker locks are based on this standard. Our Flexo and Intro series can therefore be retrofitted 1:1, easily and accurately.

16 mm